Stryke-R1 Pistol Red Dot Sight

Features

- 1. Motion Awake Technology with 3 Reticles.
- 2. Offering 50000 hours of use based on 12 brightness levels.
- 3. 10 Daylight & 2 Night Vision compatible brightness settings.
- 4. IP67 waterproof.

Structure



Specification


Stryke-R1		
Magnification	1X	
Exit Pupil	28x20mm	
Reticle	35 MOA Circle / 2MOA Red Dot	
Parallax	Free	
Material	Aviation Aluminum Alloy 6061T6	
Dimension	46(L)*30.5(W)*39.15(H) /mm	
Weight	72/42g(2.54/1.48oz)	
Battery Type	1 * CR1632	
Battery Runtime	50000 Hours	
W&E Travel Range	110MOA	
Adjustment per Click	1MOA	
Working Temperature	-30°C ∼ +60°C	
Motion Awake	Yes	
Waterproof	IP67	

Delivery Sets

☑ Stryke-R1 ☑ Wrench ☑ Cleaning Cloth ☑ User Manual

Mounting







1.Loosen the locking mounting knob, open the Picatinny rail card slot.

2.Align the guide rail with Picatinny rail card slot,click the device into the guide rail.

3.Lock the mounting knob.

Operation

- 1. **Switch on**: Momentarily press either brightness button(" "or" ") to turn on the Device.
- 2. Power off: Long press the " " button for 3 seconds to turn off the device.
- 3. **Brightness adjustment**: There are 12 settings for reticle brightness levels. Use " "or" " to increase or decrease the brightness.
- 4. Reticle selection: Long press the " "button for will cycle between the 3 reticle choices.
- 5. **Motion Awake**: After turning on the device, if there is no action within 4 minutes, the device enters sleep mode. In sleep mode, shaking can wake up the device, and the reticle is consistent with before sleep.

Maintenance & care

This device is a precision instrument that deserves reasonablycautious care. The following tips are provided toensure a longproduct life. The optical lenses are multicoated optical glass. Whencleaning the lenses, blow awayany dust on the surface, wet the lenswith lens cleaner or clean water, then wipe away smudges with lenstissue, soft cotton or a microfiber cloth. Avoid touching the glasssurface with dry cloth or tissue paper. Do not useorganic solventssuch as alcohol or acetone. No special maintenance is needed for thehousing surface. Do not tryto dismantle the device as the internalparts are specially cleaned and sealed and with an anti-fogtreatment. Any such attempt will void the warranty.